



ACCURACY SPEAKS, INC.

3960 N. USERY PASS RD. • MESA, AZ 85207 • (480)373-9499

MAGAZINE ADAPTER

If you are going to install magazine adapters on your magazines, you will need to drill a $3/16\text{V}$ (.187) hole in the bottom of the magazine. It should be centered side to side and $3/16\text{V}$ to $1/4\text{V}$ from the front of the magazine to the center of the hole. Insert the screw and tighten. Adjust the set screws to lightly contact the lower receiver, this will allow you to use the magazine for support in the standing position.

